

Safety

Ensure that your domestic mains supply voltage matches the voltage indicated on the identification sticker located at the back of your set. Where the mains plug or an appliance coupler is used as disconnect device, it shall remain readily operable. On certain models, the light indicator is located at the side of the TV set. The absence of a light indication at the front does not mean that the TV set is fully disconnected from the mains. To disconnect the TV set completely, the mains plug must be pulled out. The TV set's components are sensitive to heat. The **maximum ambient temperature** should not exceed **35°** Celsius. Do not cover the vents at the back or sides of the TV set. Leave sufficient space around it to allow adequate ventilation. Install the appliance away from any source of heat (fireplace, etc.) or appliances creating strong magnetic or electric fields. **Moisture** in rooms where the set is installed should not exceed **80%** humidity. Moving the set from a cold place to a warm one can cause condensation on the screen (and on some components inside the TV set). Let the condensation evaporate before switching the TV set on again.

WARNINGS

This appliance is intended for domestic household use only and should not be used for any other application, such as for non-domestic use or in a commercial environment. If the external flexible cable or cord of this product is damaged, it shall be replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard. Leave more than 10cm clearance around the television to allow adequate ventilation. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases shall be placed on the apparatus. Batteries shall not be exposed to excessive heat such as sunshine, fire or the like. An apparatus with CLASS I construction shall be connected to a MAINS socket outlet with a protective earthing connection.



To prevent the spread of fire, keep candles or other open flames away from this product at all times.

WARNING: To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.

CAUTION: Connect headphones with the volume set low and increase if required. Prolonged listening through headphones at high volume settings can result in hearing damage.

Eye Fatigue

When using this product as a computer monitor, health and safety experts recommend short frequent breaks rather than occasional longer breaks. For example a 5-10 minute break after an hour of continuous screen work is considered to be better than a 15 minute break every 2 hours.

Do not use the monitor against a bright background or where sunlight or other bright light sources will shine directly onto the screen.

The  or **POWER**/ button on the TV set or the  button on the remote control can be used to switch it on and put it into standby mode. If you are **not going to be watching the TV for a lengthy period of time**, switch it off completely by removing the plug from the mains power socket.

During **thunderstorms**, we recommend that you disconnect the TV set from the mains and aerial so that it is not affected by electrical or electromagnetic surges that could damage it. For this reason, keep the **mains and aerial sockets** accessible so they can be **disconnected**, if necessary.

Unplug the TV set immediately if you notice it giving off a **smell of burning** or **smoke**. You must never, under any circumstances, open the TV set yourself, as you run the risk of an **electric shock** in doing so.

TV screen

The TV screen used in this product is made of glass. Therefore, it can break when the product is dropped or impacted upon by other objects.

The TV screen is a very high technology product, giving you finely detailed pictures. Occasionally, a few nonactive pixels may appear on the screen as a fixed point of blue, green or red. This does not affect the performance of your product.

Care

Use a glass-cleaning product to clean the screen and a soft cloth and mild detergent to clean the rest of the set.

Important: Using strong detergents, alcohol-based and abrasive products may damage the screen.

Dust the vents at the back and sides regularly. Using solvents, abrasive or alcohol-based products could damage the TV set. If an object or liquid enters the appliance, unplug it immediately and have it checked by an authorized engineer. Never open the appliance yourself since this may put you at risk or damage the appliance.

Hanging the TV set on the wall

Warning: This operation requires two people.

To ensure a safe installation, observe the following safety notes:

- Check that the wall can support the weight of the TV set and wall mount assembly.
- Follow the mounting instructions provided with the wall mount. For certain models, make sure to screw

the hexagonal VESA wall mounting screw bosses (and screws) provided with the set into the nuts for the wall mount at the back of your set before your wall mounting.

- The TV set must be installed on a vertical wall.
- Make sure to use only screws suitable for the material of the wall.
- Make sure that the TV set cables are placed so that there is no danger of tripping over them.

All other safety instructions about our TV sets are also applicable here.

Placing the TV on a table and other surfaces

Before setting up your television set, make sure that the surface you want to put the set on can support its weight.

Do not place the set on an unstable surface (e.g. moving shelf, very edge of a unit) and make sure that the front of the television set does not overhang the surface it is standing on.

To avoid TV from falling please fasten TV to the wall by using necessary screws (in Vesa wall mount holes), clamps, anchors to be bought separately. Install TV near to the wall to avoid falling backwards.

Multi product user manual

The features described in this manual are common to most models. Some features may not be available on your TV and/or your TV may include features that are not described in this user manual. The illustrations in this manual may differ from the actual product. Please refer to the actual product.



Notice:
The sign Pb below the symbol for batteries indicates that this battery contains lead.

Information for Users on Disposal of Old Equipment and Batteries [European Union]

These symbols indicate that the electrical and electronic equipment and the battery with this symbol should not be disposed of as general household waste at their end-of-life. Instead, the products should be handed over to the applicable collection points for the recycling of electrical and electronic equipment as well as batteries for proper treatment, recovery and recycling in accordance with your national legislation and the Directive 2012/19/EU, 2006/66/EC and 2008/12/EC.

By disposing of these products correctly, you will help to conserve natural resources and will help to prevent potential negative effects on the environment and human health which could otherwise be caused by inappropriate waste handling of these products.

For more information about collection points and recycling of these products, please contact your local municipal office, your household waste disposal service or the shop where you purchased the product. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

[Business users]

If you wish to dispose of this product, please contact your supplier and check the terms and conditions of the purchase contract.

[Other Countries outside the European Union]

These symbols are only valid in the European Union. If you wish to dispose of these items, please do so in accordance with applicable national legislation or other rules in your country for the treatment of old electrical equipment and batteries.

Dear Customer,

This apparatus is in conformance with the valid European directives and standards regarding electromagnetic compatibility and electrical safety.

TCL Operations Polska Sp. z o.o.
ul. A. Mickiewicza 31/41
96-300 Żyrardow, Poland

Email address: zyeee@tcl.com


Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

Important information	1	Time shift	15
Chapter 1 - Connections		Reset shop	16
Connect the power and antenna	4	Customising the input settings	16
DVD player, home theatre system, PC.....	4	Using Electronic programme guide	16
DVD recorder, headphones, cable receiver	5	PVR (Personal Video Recorder)	16
Blu-ray Disc player, HD game console & HD camcorder	5	Schedule list	17
Chapter 2 - Getting started		Chapter 6 - Network	
Remote control functions	6	Network connection	18
Switch the TV on and off	7	Connecting to a wired network	18
Chapter 3 - Installing channels		Connecting to a wireless network	18
Initial setup	8	TV remote	19
Performing an automatic channel search.....	9	Miracast	19
Chapter 4 - Using your TV		Chapter 7 - DLNA (Share & See)	
Accessing channels	10	Connecting to your PC	20
Watching connected devices	10	Enabling DLNA function	20
Volume	10	Adding media from your PC for sharing	20
Using TV menus	10	DLNA application	20
Selecting menu language	10	Chapter 8 - HbbTV	
Chapter 5 - Using more of your TV		HbbTV access	21
Setting up your favourite channels	11	HbbTV deactivation	21
Energy saving	11	Chapter 9 - Smart TV	
Viewing TV using the 3D function	11	Access Smart TV Applications (Apps)	22
Audio description	11	Chapter 10 - Other information	
PAP function	12	Password in Parental Control.....	23
Using subtitles	12	Troubleshooting	23
Turning on/off subtitles	12	Television specifications	23
Enabling subtitle languages on digital TV channels	12	OSS Notice	23
Selecting a subtitle type on digital TV channels	12		
Selecting decoding page language in Teletext ...	12		
Digital Teletext language.....	12		
SPDIF type	12		
T-Link	13		
Enabling or disabling T-Link	13		
Using one-touch play	13		
Using system standby	13		
Network update.....	13		
Common interface	13		
Using the common interface module	13		
Accessing common interface services	13		
Software update	13		
Changing to Shop or Home mode.....	14		
MHEG function	14		
Viewing photos, playing music and watching videos from a USB storage device.....	14		
Photo	14		
Music	14		
Video	15		
DivX video	15		
Time access	15		
Diagnostics on digital TV channels	15		

Connect the power and antenna

To switch on TV after connecting power cord, press **⏻** or **POWER/⏻**.

Note: Position of power socket varies according to TV model. On certain models, you have to turn on the power switch first.



Notes: - Disconnect the power cord before connecting devices.


- Position of TV ports varies according to TV model.

DVD player, home theatre system, PC

Notes: - Before connecting a PC, set the PC monitor refresh rate to 60Hz.

- It is recommended to use as short as possible high quality HDMI cables to avoid possible interferences.


- It is recommended to use 1m long or shorter VGA cable with ferrite beads in case VGA input is available in TV and TV is connected using VGA cable. Maximum supported VGA resolution is 1024x768/60Hz.



DVD recorder, headphones, cable receiver

Note:

- Excessive sound pressure from earphones and headphones can cause hearing loss.




Blu-ray Disc player, HD game console & HD camcorder

Notes:

- USB connectors are for data input from USB drives and for connecting other relevant USB devices where applicable.
- All USB devices have to be directly connected to TV set without cable extenders. In case extender is required it has to be as short as possible and equipped with ferrite beads.
- ARC (Audio Return Channel) function is only supported on the HDMI port identified with ARC.
- Number of USB ports may vary.

Notes:

- Not all connections available on all models.
- The location of the power socket on the TV may vary according to TV model.
- The positions and names of the function buttons and connectors on the TV may vary according to TV model.




Chapter 2 - Getting started

Remote control functions

Most of your television's functions are available via the menus that appear on the screen. The remote control supplied with your set can be used to navigate through the menus and to configure all the general settings.

Note: You are recommended to use the full screen mode. Do not use the display mode with black bars on both sides of the picture (such as 4:3) for a long time; otherwise the TV screen may be damaged permanently.



Important:

Batteries shall not be exposed to excessive heat such as sunshine, fire or the like. Remove batteries when the remote control is not to be used for a long time. Batteries left in equipment may cause damage through deterioration and corrosive leakage, invalidating the guarantee.

To protect the environment use local recycling facilities for battery disposal. Dispose of used batteries according to the instructions.

CAUTION: Risk of explosion if batteries are replaced by an incorrect type. Replace only with the same or equivalent type recommended by the equipment manufacturer.

If the batteries in your remote control are run down, you can use the buttons on your TV set. They have the following functions:

For models with below buttons on the set:

	TV mode	In menus
PR+ or PR ▲	P+	▲
PR- or PR ▼	P-	▼
VOL+ , ▲ + or VOL ►	V+	►
VOL- , ▼ - or VOL ◀	V-	◀
MENU or ≡	MENU	MENU
OK or ⏏	OK	OK
⏻	⏻	⏻

For models with below buttons on the set:

	TV mode	In menus
P+	▲	
P-	▼	
V+	►	
V-	◀	
⏻		
	Features (Short press)	OK (Short press)
		Return (Long press)

Switch the TV on and off

1. When the power cord is connected, the TV will be turned on directly or be in standby mode. If the TV is in standby mode, press the **⏻** or **POWER/⏻** button on the set or the **⏻** button on the remote control to turn it on.
2. To put the TV into standby mode, press the **⏻** or **POWER/⏻** button on the set or the **⏻** button on the remote control. The TV set remains powered up, but with low energy consumption.
3. To switch the TV off, unplug the mains plug from the mains outlet.

(*On certain models, you have to turn on the power switch first.)

Initial setup

Initial setup involves selecting all the settings required to be able to search for and store all the analogue and digital channels you can receive.

Make sure that the television is switched on and follow all the steps in turn specified hereafter.

Note: If the channel search retrieved only the analogue channels it could be caused by poor broadcasting and therefore is not covered by manufacturer warranty. Manufacturers cannot be held responsible for lack of or poor broadcasting in some areas.

The first time you switch the set on, the **Initial setup** wizard opens, which guides you through the initial setup process. (Refer to Figure 1.)




Figure 1

1. Press **▲/▼** to select your language, then press **OK/▶** to enter the next step.
2. Press **▲/▼** to select your country, then press **OK/▶** to enter the next step. Press **▲/▼** to select your location, then press **OK/▶** to enter the next step. Press **▲/▼** to select to continue or skip network connection setup, then press **OK/▶** to enter the next step.

*Note: If you select **France** or **Italy**, you will have to enter the **Password setting** menu here to set a password. Use the alphanumeric buttons to enter a four-digit number for your password. (0000 is too simple to be set as your password.) Re-enter the same code to confirm the password. After that, you will enter the next step automatically. (In this step, you can only press **◀** to return to the previous step.)*

3. Press **▲/▼** to select your tuner mode **Antenna** or **Cable** or **Satellite**.

*(Note: **Satellite** option may not be available for certain models.) Then follow a) or b) or c) below.*

- a) If you have selected **Antenna**.
 - Press **OK/▶** to enter.
 - Press **▲/▼** to select **Digital & Analogue** or **Digital** or **Analogue**, then press **OK/▶**.

- Press **▲/▼** to select **Scan**, then press **OK/▶** to start the automatic search for all DVB-T digital and/or analogue channels.

*Note: not all countries have **Favorite Network Selection** function.*

- b) If you have selected **Cable**.
 - Press **OK/▶** to enter.
 - Press **▲/▼** to select **Digital & Analogue** or **Digital** or **Analogue**.
 - If you select **Digital & Analogue**, press **OK/▶** to enter. Then:
 - Press **▲/▼** to select **Scan**, then press **OK/▶**.
 - Press **◀/▶** to select the scan mode if available (**Full** or **Advanced**).
 - If you select **Full**, press **OK** to start the automatic search for all DVB-C digital and/or analogue channels.
 - If you select **Advanced**, use the numeric buttons to adjust the values for **frequency**, **symbol rate**, **network ID**, and use **◀/▶** to select the **modulation mode**; then press **OK** to start the search for all DVB-C digital and/or analogue channels.
 - If you select **Digital**, press **OK/▶** to enter, then follow all the same steps as for **Digital & Analogue** above, to search for all DVB-C digital channels.
 - If you select **Analogue**, press **OK/▶** to enter, press **▲/▼** to select **Scan**, then press **OK/▶** to start the search for all analogue channels.
- c) If you have selected **Satellite**.
 - Press **OK/▶** to enter.
 - Press **▲/▼** to select one operator and press **OK/▶**.
 - Press **▲/▼** to select one satellite, then press **OK** to configure the proper information related to this satellite. Press **OK** to go back after finishing settings.
 - Press **▶** to start scanning.

Note: To prevent the channel setup process from being interrupted, wait for the message indicating that the setup is complete.

4. Before starting the scanning, you can also select **Skip scan** to skip the initial setup process. In this case, to search and store your channels you may do an automatic channel search by following the instructions in the next section **Performing an automatic channel search**.
5. During the setup, you can follow the hints available at the bottom of the screen to return to the previous step by pressing **◀**. Or press **EXIT** to exit or interrupt the search halfway.
6. In this step, you can press **OK** to exit the initial setup. The channels are arranged in a preset order. If you wish to skip channels, modify the preset order or rename channels, select **Setup > Organiser** and press **OK/▶** to enter. In this step,

you can also press ◀ to return to the previous step.

Performing an automatic channel search

This section describes how to search and store channels automatically. Instructions are for both analogue and digital channels. This may be done in any of the cases below:

- you have selected **Skip scan** in the Initial setup
 - you see **"Please scan channels!"** in TV mode
 - you want to update your channels.
1. Press **MENU** on the remote control and select **Settings > Setup > Language**. Press **OK/▶** to enter and press ◀/▶ to select your desired menu language.
 2. Press **MENU** to return to **Setup**, press ▲/▼ to select **Country**, then press ◀/▶ to select your country. The TV installs and arranges channels according to your country. At this step, you will be requested to enter your password.
 3. Press ▲/▼ to select **Tuner mode**, then press ◀/▶ to select **Antenna** or **Cable** or **Satellite**. (Note: **Satellite** option may not be available for certain models.) Then follow a) or b) or c) below.
 - a) If you have selected **Antenna**.
 - Press ▲/▼ to select **Channel install**, and press **OK/▶** to enter.
 - Select **Automatic search** (Refer to Figure 2.), then press **OK/▶** to display **Automatic search**.




Figure 2

- Press **OK** to skip the country selection and enter the next step. Or use ◀/▶ to reselect your country, then press **OK** to enter.
 - Select **Digital & Analogue** or **Digital** or **Analogue**, then press **OK/▶** to start the automatic search, which relates to all DVB-T digital and/or analogue channels.
- b) If you have selected **Cable**.
 - Press ▲/▼ to select **Channel install**, and press **OK/▶** to enter.
 - Select **Automatic search**, then press **OK/▶** to display **Automatic search**.

- Press **OK** to skip the country selection and enter the next step. Or use ◀/▶ to reselect your country, then press **OK** to enter.
 - If you select **Digital & Analogue**, then press **OK/▶** to enter. Select your scan mode if available and configure proper cable information in the same way as in Initial setup. Press ▲/▼ to select **Scan** and press **OK/▶** to start your automatic search relating to all DVB-C digital and analogue channels.
 - If you select **Digital**, then follow the same process as above to start your automatic search relating to all DVB-C digital channels.
 - If you select **Analogue**, then press **OK/▶** to start your automatic search relating to all analogue channels.
 - c) If you have selected **Satellite**.
 - Press ▲/▼ to select **Channel install**, and press **OK/▶** to enter.
 - Select **Automatic search**, then press **OK/▶** to enter. You can select a proper satellite or an operator.
 - Press **OK** to go to the next step. Before you start scanning, you can select **Satellite Setup** and press **OK** to select a satellite and press **OK** to edit the parameters of the selected satellite. Then with your desired options of **Scan mode** and **Channels**, select **Scan** and press **OK/▶** to start scanning.
4. The search may take a few minutes. During the process, you can press **MENU** to abort halfway.
 5. Once the automatic search ends, press **MENU** to return to the previous step or press **OK** to restart your channel search.
 6. After the automatic search, channels are arranged in a preset order. If you wish to skip channels, modify the preset order or rename channels, select **Settings > Setup > Organiser** and press **OK/▶** to enter.

Chapter 4 - Using your TV

Accessing channels

Using the numeric buttons: press the corresponding numeric buttons on the remote control to access the channels.

Using the P+/- buttons: press the **P+/-** buttons on the remote control or the corresponding buttons on the TV set to scroll through the channels.

Watching connected devices

Repeatedly press **SOURCE** on the remote control or **OK** on the TV set to toggle between TV and other input sources. To resume TV viewing, press any numeric button to enter the channel, while **P+/-** will cycle through all TV channels and other input sources.

*Note: Not all models have **OK** button on the set.*

Volume

Volume control: press the **V+/-** buttons on the remote control or the corresponding buttons on the TV set to increase or decrease the volume.

Sound mute: press the  button to temporarily mute the sound. Press this button again or the **V+** button to restore it.

Using TV menus

1. Press **MENU** to display the main menu. (Refer to Figure 3.)




Figure 3

2. Press **▲/▼/◀/▶** to select the desired item, then press **OK** to open the corresponding submenu.
3. In submenus, use **▲/▼** to select menu options, use **◀/▶** to set functions or change values. Use **OK** to activate a setting. Use **OK/▶** to open the corresponding submenu.
4. Press **MENU** to return to the previous menu.
5. Press **EXIT** to close the menu.

Note: Some options may not be available for certain signal sources.

Selecting menu language

You can choose your preferred menu language following the instructions below.

1. Press **MENU** to display the main menu.
2. Press **▲/▼/◀/▶** to select **Settings > Setup**, then press **OK** to enter.
3. Select **Language** and press **OK/▶** to enter.
4. Press **◀/▶** to select your desired language in the **Language** menu to display the menus.
5. Press **EXIT** to close the menu.

Setting up your favourite channels

You can create a list of your favourite TV channels.

1. Press **LIST**.
2. Press the yellow button to enter **Channel list selection**. Press **▲/▼** to select the favourite list and press **OK** to enter.
3. Press the blue button to start editing your favourite list. Press **▲/▼** to scroll through the channel list and press **OK** to select or deselect it.
4. Repeat this procedure to set up other favourite channels.
5. Press **LIST/EXIT** to exit.

Shortcut operation: Press **FAV** on the remote control to directly enter **Channel list selection**.

Energy saving

1. Press **MENU** on the remote control and select **Picture > ECO Settings > Energy Saving**.
2. Press **◀/▶** to select a desired power saving mode to achieve the desired power saving effect.
3. Press **EXIT** to close the menu.

Shortcut operation: Press **ECO** on the remote control to select a desired power saving mode directly.

Viewing TV using the 3D function

(* not available for some models)

WARNING:

- Some viewers may experience discomfort while viewing 3D TV such as dizziness, nausea and headaches. If you experience any such symptom, stop viewing 3D TV, remove your 3D glasses and rest.
- Watching 3D videos too closely or for a long period of time may harm your eyesight.
- A responsible adult should frequently check on children who are using the 3D function.
- Do not use the 3D glasses for any other purpose than viewing 3D videos on a 3D TV.
- Do not use the 3D function or 3D glasses while walking or moving around, otherwise this may result in injuries due to running into objects, tripping, and/or falling.

1. Press **MENU** on the remote control and select **Picture > 3D navigation**, then press **◀/▶** to adjust **3D navigation** to **Manual**.
2. Press **▲/▼** to select **3D** in the **Picture** menu and press **OK/▶** to enter the **3D** menu. (Refer to Figure 4.)
3. Wear the 3D glasses first, then select **3D mode** and press **◀/▶** to select the desired 3D input format for the playing of 3D video.




Figure 4

4. Press **▲/▼** to select other menu options:
 - **3D-to-2D:** Select **Left** or **Right** to display the image in 2D mode (no 3D effect). This function is deactivated when **3D mode** is set to **2D-to-3D** or **Off**.
 - **Depth of field, Protrude, Distance to TV:** Press **◀/▶** to adjust to achieve a good 3D effect with the image.
 - **Image safety:** Press **◀/▶** to select a desired option among **Low**, **Middle**, **High** and **Off**.
 - **L-R switch:** Select **On** or **Off** to adjust the 3D video between the left and right eyes for better 3D viewing.
5. Press **EXIT** to close the menu.

Notes:

- 3D glasses from other manufacturers may not be supported.
- All photo functions are disabled in 3D mode.
- If you change to a different signal source or access Smart TV, the 3D mode will be automatically disabled.
- Some 3D modes may not be available depending on the input format of the 3D video source.
- Supported 3D modes:
 Analogue TV, AV: **2D-to-3D**
 Digital TV: **Top and Bottom, Side-by-Side, 2D-to-3D, Line interleave**.
 CMP, HDMI, USB, Videos from the Internet: **Top and Bottom, Side-by-Side, 2D-to-3D, Line interleave, Frame sequential**.
- 3D function in USB mode: During the playback of a selected video from USB, press **MENU** to display the video menu in the browser mode, then select **3D Mode**. For more detail information, refer to the above related descriptions.

Audio description

Audio description refers to an additional narration track for blind and visually impaired viewers of visual media, including television programmes and movies. The description narrator talks through the presentation describing what is happening on the screen during the natural pauses in the audio (and during dialogue if deemed necessary).

You can use this feature if the current broadcast contains audio description.

1. Press **MENU** on the remote control and select **Sound**, then press **OK** to enter.
2. Use **▲/▼** to select **Audio Description**, then press **OK** to enter.
3. You can turn the Audio Description function on or off in the **Audio Description** menu.
4. To adjust the volume for Audio Description, press **▲/▼** to go to the next menu line, then use **◀/▶** to set the volume.

PAP function

Use this function to display the pictures from different source inputs side by side. Note that one window is for both analogue and digital TV inputs, the other is for VGA, HDMI and CMP inputs. *(Note: Not available for AV input on both windows. For some models, VGA input is not available.)*

1. Press **MENU** to display the main menu.
 2. Select **Picture** and press **OK** to enter.
 3. Press **▲/▼** to select the **PAP** option, and press **OK** to enter.
 4. Press **◀/▶** to turn on/off PAP function.
 5. Select **TV position**, press **◀/▶** to reposition the TV window.
 6. Press **EXIT** to close the menu.
- If you switch on the PAP function, you can press **◀/▶** to toggle the focus window. When the focus is on the TV window, the alphanumeric buttons and **P+/-** work in TV mode. When the focus is on the other window, **P+/-** switches available external sources.

Using subtitles

You can enable subtitles for each TV channel. Subtitles are broadcast via Teletext or DVB-T/DVB-C digital broadcasts. With digital broadcasts, you have the additional option of selecting a preferred subtitle language.

Turning on/off subtitles

1. Press **MENU** on the remote control and select **Settings > Subtitle**.
2. Press **OK/▶** to enter. (Refer to Figure 5.)




Figure 5

3. Select the **Subtitle** option, and press **◀/▶** to select **On/Off** to turn on/off subtitles.

Enabling subtitle languages on digital TV channels

1. Press **MENU** on the remote control and select **Settings > Subtitle > Digital subtitle language**.
2. Press **◀/▶** to select a subtitle language as your preferred language.
3. Press **▲/▼** to select **Digital subtitle language 2nd**.
4. Press **◀/▶** to select a secondary subtitle language.
5. Press **EXIT** to close the menu.

Shortcut operation: Press **SUBTITLE** on the remote control to directly select a subtitle language available for the selected digital TV programme.

Selecting a subtitle type on digital TV channels

1. Press **MENU** on the remote control and select **Settings > Subtitle > Subtitle type**.
2. Press **◀/▶** to select a subtitle type. You can select **Hearing impaired** to display the hearing impaired subtitles with your selected language.

Selecting decoding page language in Teletext

Press **MENU** on the remote control and select **Settings > Teletext > Decoding page language**. Select a proper type of language in which Teletext will display.

Digital Teletext language

On digital TV channels, depending on the broadcaster, you may be able to enjoy a service with multiple initial Teletext pages in different languages. This function allows you to select an available language as primary language, which relates to different initial Teletext pages.

Press **MENU** on the remote control and select **Settings > Teletext > Digital teletext language**. Press **◀/▶** to select.

SPDIF type

Connect the TV to an audio device through the **SPDIF** output. To select a proper sound type for your SPDIF output, press **MENU** on the remote control and select **Settings > SPDIF type**.

- If you select **PCM**, the SPDIF output format is PCM, regardless of the programme's sound format.
- If you select **Dolby D**, the SPDIF output format is
 - Dolby Digital when the programme's sound format is Dolby Digital or Dolby Digital Plus or HE-AAC
 - PCM when the programme's sound format is MPEG.
- If you select **Off**, this turns off the audio output from the audio device connected to the SPDIF output.

*Note: The options you may choose depend on the programme you are watching. If you select **PCM** and the sound is ahead of the picture, you can select **SPDIF delay** from the **Settings** menu and press ◀/▶ to adjust the delay time to synchronize the sound with the picture.*

T-Link

Use this function to search for CEC devices connected to the HDMI sockets in your TV and enable one-touch play and one-touch standby between CEC devices.

Enabling or disabling T-Link

1. Press **MENU** on the remote control, then select **Settings > T-Link**.
2. Press ◀/▶ to select **On** or **Off**, if this function is turned on, **T-Link** option will be available in the **Quick access** menu which you can enter by pressing the **Option** button on the remote control.

Using one-touch play

With one-touch play, pressing the play button on (for example) your DVD remote control starts playback on your DVD device and automatically switches your TV to the correct source, displaying DVD content.

Using system standby

With system standby, pressing the ⏻ button on (for example) your TV remote control switches your TV and all connected HDMI devices to standby mode.

Note: The CEC functions depend on the devices connected and it is possible that some devices may not interoperate correctly when connected to this TV. The user manual or the manufacturer of the problematic devices should be consulted for further information.

Network update

Press **MENU** on the remote control, then select **Settings > Network update**. Select **On/Off** to enable or disable the Network update function.

- When this function is on, the TV will automatically update channels if your DTV service provider updates their DTV network.
- When this function is off, you need to run the channel search again to get new channels or remove unavailable channels if your DTV service provider adds or removes channels from their DTV network.

Common interface

Encrypted digital TV channels can be decoded with a common interface module and a card provided by a digital TV service operator.

The common interface module may enable several digital services, depending on the operator and

services you choose (for example, pay TV). Contact your digital TV service operator for more information about services and terms.

Using the common interface module

WARNING: Switch off your TV before inserting a common interface module. Be sure to follow the instructions described below. Wrong insertion of a common interface module may damage both the module and your TV.

1. Following the directions printed on the common interface module, gently insert the module into the common interface slot on the TV.
2. Push the module in as far as it will go.
3. Turn on the TV and wait for the common interface function to be activated. This may take several minutes.

Note: Do not remove the common interface module from the slot. Removing the module will deactivate the digital services.

Accessing common interface services

After inserting and activating the common interface module, press **MENU** on the remote control and select **Settings > Common interface**.

This menu option is only available if the common interface module is correctly inserted and activated. On-screen applications and content are provided by your digital TV service operator.

Software update

Note: Do not switch off or unplug the TV until the upgrade is completed.

Press **MENU** on the remote control and select **Settings > Software update**. Press **OK/▶** to enter.

- **By network:** Enables you to download and install the latest software version from the Internet. Make sure to set up a wired or wireless network connection first then select **By network** and press **OK/▶** to enter. When new-version software is available, a progress bar appears. When the download finishes, the TV will go black and upgrade the software.

Note: Keep successful network connection during upgrade.

- **By channel:** Enables you to install the latest version of the software if available from the broadcast. Use ▲/▼ to select **By Channel** and press **OK/▶** to enter.
 - Use ◀/▶ to select **Yes** under **Auto download** to automatically download the latest software if available. After the software has been downloaded successfully, you will be prompted to decide if you want to install it right now. If yes, follow the on-screen instructions to complete your installation. You can also select to ignore the installation here.

- Use ◀/▶ to select **No** under **Auto download** to decline the automatic download.
- Use ▲/▼ to select **Manual Download** and press **OK/▶** if you wish to search manually for the latest software. Follow the on-screen instructions to complete. During the search, press **OK/EXIT** to cancel or exit the process.

Changing to Shop or Home mode

1. Press **MENU** on the remote control and select **Settings > Location**.
2. Press ◀/▶ to select your location **Shop** or **Home**.
3. Press **EXIT** to exit.

*Note: According to the regulation of European Commission 2009/125/EC, in Home mode, TV will be put into standby mode automatically if there is no operation in 4 hours. This feature can be deactivated in the **Settings > Timer > Auto standby** menu.*

MHEG function

Some digital TV broadcasters offer dedicated digital text or interactive services (for example, BBC1). These services work like normal Teletext with the addition of number, colour and navigation buttons.

*Note: MHEG and subtitles are mutually exclusive and cannot coexist on the same screen. If **Subtitle** is set to **On**, MHEG will not appear. Please follow the instructions in the section **Turning on/off subtitles** to set **Subtitle** to **Off**.*

1. Press the red button or **TEXT** on the remote control.
2. Press ▲/▼/◀/▶ to select or highlight items.
3. Press **OK/▶** to confirm or activate.
4. Press one of the colour buttons to select an option.
5. Press **TEXT** or **EXIT** to exit.

Viewing photos, playing music and watching videos from a USB storage device

Your TV is fitted with a USB connector that enables you to view photos, listen to music or watch videos stored on a USB drive.

Supported file formats:

Photo	JPEG
Music	MP3
Video	AVI, MPG, MPEG, TS, DIVX, MKV...

Note: Some USB keys and USB products like digital cameras or mobile phones are not fully compatible with USB 2.0 standard so they may not work with the TV multimedia player. Not all USB keys or devices are compatible with the USB function. Not all above formats are recognised. The encoding

formats of your files will determine whether or not they can be used.

When a USB drive is detected, the TV enters the **Media center** menu directly. To enter the **Media center** menu manually, press **MENU** on the remote control and select **Media**.

Photo

Use this function to display photos, if available.

1. Select **Media > Photo**, then press **OK** to enter the main file content browser.
2. In the main file content browser, use ▲/▼/◀/▶ to select a photo or an inner file folder.
3. Select an inner file folder, press **OK** to enter a sub file content browser.
4. Use ▲/▼/◀/▶ to select a photo in either main or sub file content browser, press **MENU** to display the photo menu in folder mode.
 - **Sort:** Sort folders and photos by modification Date or Name.
 - **Edit:** Copy, paste or delete a selected photo.
 - **Parser:** You can select **Recursive** to display photos from all sub file folders.
5. Select a photo, press **OK** to watch, and a slide show begins from the selected photo. Press **OK** to pause the photo. Press **MENU** to display the photo menu in the browser mode. You can play, pause or rotate the photo, select different play modes and display effects, etc.
6. Press the related buttons on the remote control to perform the available functions shown on the function bar at the bottom of the TV screen. Press the **INFO** button to show or remove the function bar.

Music

Use this function to play back music, if available.

1. Select **Media > Music**, then press **OK** to enter the main file content browser.
2. Use ▲/▼/◀/▶ to select a song in either main or sub file content browser in the same way as in photo display function, press **MENU** to display the music menu in folder mode.
 - **Sort:** Sort folders and songs by Name, Genre, Artist or Album.
 - **Edit:** Copy, paste or delete a selected song.
 - **Parser:** You can select **Recursive** to display songs from all sub file folders.
3. Select a song, press **OK** to play, and automatic playback begins from the selected song. Press **MENU** to display the music menu in the browser mode. You can play or pause the song, select different play modes, etc.
 - **Show lyrics:** This option is available for the songs with lyrics. Select it and use ◀/▶ to turn on/off lyrics synchronized display.

- **Audio only:** Select and press **OK** to listen to the music with the screen turned off. Any key press will turn the screen on.
- 4. Press the related buttons on the remote control to perform the available functions shown on the function bar at the bottom of the TV screen.

Video

Use this function to watch videos, if available.

1. Select **Media > Video**, then press **OK** to enter the main file content browser.
2. Use **▲/▼/◀/▶** to select a video in either main or sub file content browser in the same way as in photo display function, press **MENU** to display the video menu in folder mode.
 - **Sort:** Sort folders and videos by Type, modification Date or Name.
 - **Edit:** Copy, paste or delete a selected video.
 - **Parser:** You can select **Recursive** to display videos from all sub file folders.
3. Select a video, press **OK** to watch, and automatic playback begins from the selected video. Press **MENU** to display the video menu in the browser mode. You can play or pause the video, select different play modes, screen modes and preset picture settings, etc.
4. Press the related buttons on the remote control to perform the available functions shown on the function bar at the bottom of the TV screen. Press the **INFO** button to show or remove the function bar.

DivX video

(* not available for some models)

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies.

Obtain your registration code:

- Press **MENU** on the remote control.
- Select **Settings > DivX(R) registration**.
- Press **OK/▶** and your registration code will be displayed.

Go to vod.divx.com for more information on how to complete your registration.

Deregister your TV:

If you wish to deregister your TV,

- Press **MENU** on the remote control.
- Select **Settings > DivX(R) deregistration**.
- Press **OK/▶** and a message will guide you.

DivX®, DivX Certified®, DivX Plus® HD and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

Time access

You can access the time from digital channels following the instructions below.

1. Press **MENU** on the remote control and select **Settings > Timer > Clock > Auto synchronization**.
2. Press **◀/▶** to select **On**.

Diagnostics on digital TV channels

1. Press **MENU** on the remote control and select **Settings > Setup > Diagnostics**.
2. Press **OK/▶** to display some signal information on the current digital channel, such as signal strength, frequency, etc.

Time shift

Allows you to record the TV programme so that you will not miss the favourite part even if you go out. Before you use the function, connect a USB drive to the TV first. For the first time, you should do the disk setup for the USB drive.

*Note: This feature is available only in selected products and, due to specific TV network limitations and country technical requirements, might not be available in product or place of installation. This feature might also be blocked by TV network due to copyright protection (HD content, recording protection). Please use **OPTION** on the remote control to check if this feature is available in your product.*

1. Press **MENU** on the remote control and select **Settings > Setup > Time shift**.
2. Press **◀/▶** to select **On** to switch on the time shift function, then press **EXIT** to close the menu.
3. Press **OPTION** on the remote control and select **Time shift**, then press **OK** to confirm.
4. Follow the directions on the screen to do the setup.
5. After the disk setup is done, press **OPTION** and select **Time shift**.
6. Press **OK** to display the time shift menu.
 - Press the red button to pause the picture and begin the time shift.
 - Press the red button to play the recorded part.
 - When the time shift menu disappears and only the timing of the time shift remains on the screen, you can press the red button or **OK** to access the time shift menu.
 - Press the green button to fast backward or the yellow button to fast forward.
 - Press the blue button to quit the time shift function.

Notes:

- Before you connect the USB drive to the TV, make sure you have backed up the data in the drive to avoid the loss of your important data due to unforeseen malfunction.
- We recommend you use a USB drive with free capacity above 1GB and disk speed faster than 5.0MB/sec.
- The bigger the USB drive free memory for time shift, the bigger the recording length.
- If you change the channel in time shift mode, a message prompts you to select **Yes** or **No**. You can select **Yes** to exit the time shift function and execute the channel change.

Reset shop

Allows you to reset the TV to factory default settings.

1. Press **MENU** on the remote control and select **Settings > Setup**, then press **OK** to confirm.
2. Select **Reset shop** and press **OK/▶** to enter.
3. Use the alphanumeric buttons to enter the password.
4. Press **◀/▶** to select **OK** and press **OK** to confirm.
5. The **Initial setup** menu appears. Follow the related instructions.

Customising the input settings

You can configure your TV according to the equipment you connect to it.

1. Press **MENU** on the remote control and select **Settings > Setup > Input settings**.
2. Press **OK/▶** to enter **Input settings**.
3. Press **▲/▼** to select a connector your equipment is connected to.
4. Press **◀/▶** to select the type of apparatus attached to this connector.
5. Press **MENU** to return to the **Setup** menu.

After configuring, the selected source label will be displayed after the name of the related connector in the source list when pressing **SOURCE** on the remote control or **OK** on the TV set.

*Note: Not all models have **OK** button on the set.*

Using Electronic programme guide

EPG is an on-screen guide that displays scheduled TV programmes. You can navigate, select, view and record programmes.

1. Press **GUIDE** on the remote control, the **Now and Next EPG** menu will appear, which allows you to get information about the current or next programme playing on each channel. Navigate through the different programmes using the navigation buttons on the remote control.
2. Use the colour buttons to view the **8 Days EPG**.
 - **Prev day** (Red): List the previous day's EPG.
 - **Next day** (Green): List the next day's EPG.

- **View detail** (Yellow): Display the description of this programme if available.
- **Type filter** (Blue): Programme guide filter for digital TV programmes.
 - Press the blue button to display the programmes' type and subtype lists.
 - Navigate through the different types and subtypes using the navigation buttons on the remote control.
 - Select one or more types, which you want to highlight from the **Type** list, press **OK** to select (or deselect). A checkmark will appear to the left of the type when selected. When you select a type, all its subtypes will be selected accordingly.
 - Also, you can select some desired subtypes without selecting any type first.
 - Press the blue button to exit the type and subtype list.
 - After filtering, all your desired digital TV programmes will be highlighted.
- **Add schedule** (Option): Press **OPTION** on the remote control to bring up the **Schedule list** menu. For details on scheduled recording, refer to the **Schedule list** section.
- 3. Press **GUIDE/EXIT** to exit the EPG and switch to the selected channel.

PVR (Personal Video Recorder)

Allows you to record your favourite TV programmes. Before you use the function, connect a USB drive to the set first.

*Note: This feature is available only in selected products and, due to specific TV network limitations and country technical requirements, might not be available in product or place of installation. This feature might also be blocked by TV network due to copyright protection (HD content, recording protection). Please use **OPTION** on the remote control to check if this feature is available in your product.*

1. Press **OPTION** on the remote control and select **Quick access > PVR**.
2. Press **OK/▶** to enter.
3. Press:
 - the red button to start recording, the record file is put into a folder named after the channel number under the PVR folder in **Media > Video**;
 - **▲/▼/◀/▶** to adjust the recording duration.
 - the green button to stop recording manually; in normal operation, the recording will stop automatically when the recording duration has passed.
4. In recording, PVR mini pane will also show on the screen to indicate the recording progress.

5. To watch the recorded programme, exit PVR mode first and go to **Media > Video**. Select the folder PVR, then select the related record file. Press **OK** to play. (It is the same if you record a digital radio programme).

Notes:

- *This feature is available only for non encrypted digital channels. Even when CICAM (CI or CI+) is inserted, this feature is not available on encrypted channels.*
- *Before you connect the USB drive to the set, make sure you have backed up the data in the drive to avoid the loss of your important data due to unforeseen malfunction.*
- *The bigger the USB drive free memory for the PVR function, the bigger the recording length.*
- *If you want to change channel or signal source during recording, store the recording data before changing the channel or source.*
- *The set cannot play files normally if the parameters of the file exceed the limitations of the system, the file format is not supported, the file is damaged, or the file cannot be decoded.*
- *Do not disconnect the USB drive when the system is reading a file or transmitting data, otherwise the system or the drive may be damaged.*

4. Press **▲/▼/◀/▶** to select **Add**, then press **OK** to add the schedule you set into your schedule list.
5. Press the red button to repeat above procedures to add another schedule.
6. If you wish to edit or delete a schedule, select it and press **OK** to enter.
7. Press **EXIT** to close the menu.

Schedule list

This function is used to perform scheduled recording.

1. Press **OPTION** on the remote control and select **Quick access > Schedule list**.
2. Press **OK** to display the schedule list.
3. To add a schedule into your schedule list, press the red button first to display **Schedule list**. Then,
 - **Channel number**: use **◀/▶** to select the channel number.
 - **Start date**: use the alphanumeric buttons to set the recording date.
 - **Start time**: set the starting time of the recording.
 - **Stop time**: set the stopping time of the recording.
 - **Schedule type**:
 - Set **Reminder** to be reminded that you can switch to the scheduled programme when the time you have set comes. When time is out and you do not execute any operation, the dialogue box will disappear and no further operation will be executed.
 - Set **Record** (if available), if you really want to start your scheduled recording when the time you have set comes. When time is out and you do not execute any operation, scheduled recording will start automatically.
 - **Repeat type**: set different repeat modes for the recording.

Chapter 6 - Network

Network connection

You can set up your TV so that it can access the Internet through your local area network (LAN) using a wired or wireless connection.

Connecting to a wired network

You can attach your TV to your LAN using cable in three ways:

- You can attach your TV to your LAN by connecting the LAN port on your TV to an external modem using a Cat 5 cable.
 - You can attach your TV to your LAN by connecting the LAN port on your TV to an IP Sharer, which is connected to an external modem. Use Cat 5 cable for the connection.
 - Depending on how your network is configured, you may be able to attach your TV to your LAN by connecting the LAN port on your TV directly to a network wall outlet using a Cat 5 cable. Note that the wall outlet is attached to a modem or router elsewhere in your house.
1. Press **MENU** on the remote control and select **Network > Network settings > Internet connection**. Press **◀/▶** to select **On**.
 2. Press **▲/▼** to select **Interface**, then set **◀/▶** to **Ethernet** to select wired-mode connection.
 3. Press **▲/▼** to select **Connection test**, then press **OK/▶** to check the Internet connectivity. If it does not work, follow step 4 below.
 4. Select **Network > Network settings > IP setting**, then press **OK/▶** to enter the **IP setting** menu. You can set **Address type** to **Auto** or **Manual**.
 - Select **Auto** if you want the TV to acquire and enter the needed IP address automatically.
 - Select **Manual** if you want to enter your IP address manually, then:
 - Press **▼** to go to the first entry field.
 - Enter the **IP address**, **Subnet mask**, **Default gateway**, **Primary DNS** and **Secondary DNS** values. Use the alphanumeric buttons to enter numbers and the arrow buttons to move from one entry field to another.
 - Once **Auto** or **Manual IP setting** is completed, press **MENU** to go back, press **▲/▼** to select **Connection test**, then press **OK/▶** to check the **Internet connectivity** again.
 5. If you want to see the information on current connection, such as **Interface**, **Address type**, **IP address**, etc., select **Network > Network settings > Information**, then press **OK/▶**.

Connecting to a wireless network

To connect your TV to your network wirelessly, you need a wireless router or modem and a Wireless LAN Adapter (some TV models are equipped with an integrated LAN Adapter). Connect your Wireless

High-Gain USB Adapter (USB dongle) delivered with your TV to your TV's **USB 1** port.

1. Press **MENU** on the remote control and select **Network > Network settings > Internet connection**. Press **◀/▶** to select **On**.
2. Press **▲/▼** to select **Interface**, then set **◀/▶** to **Wireless** to select wireless-mode connection.
3. Press **▲/▼** to select **Wireless setting** and press **OK/▶** to enter.
4. You can set up the wireless network connection in 3 ways: a) or b) or c).

- a) Scan

- Press **▲/▼** to select **Scan**, then press **OK/▶**. The TV will search all access points within range, access points found by the TV will be displayed.
- Press **▲/▼** to select an available access point, then press **OK/▶** to connect the TV.

Notes:

- If you select a protected access point, you will have to enter the corresponding password. Press **OK** on the remote control to display the virtual keyboard to enable you to enter the password.
- This set is able to memorize the available access point, which enables it to connect to the network even if you switch on your TV after power-off.

- b) Manual

Press **▲/▼** to select **Manual**, then press **OK/▶**, you will be prompted to enter the correct SSID of an available wireless router to set up the connection.

- c) Auto

If your AP (Access Point) supports WPS (Wi-Fi Protected Setup), you can connect to the network via PIN (Personal Identification Number) or PBC (Push Button Configuration). WPS will automatically configure the SSID and WPA key in either mode.

Press **▲/▼** to select **Auto**, then press **OK/▶** to enter.

- **PIN:** Select **PIN** and press **OK/▶** to enter. Choose a random PIN code. Make sure this code is installed on the AP. (For the procedures, refer to your router manual.) Press **OK/▶** again to set up the connection.
- **PBC:** If your router has a PBC push button, select **PBC**, then press **OK/▶** to enter. Press the PBC push button on your router within 2 minutes after you press **OK/▶** again. Your TV will automatically acquire all the network setting values it needs and connect to your network.

5. To check the Internet connectivity, follow the instructions in steps 3 and 4 of the preceding section **Connecting to a wired network**.
6. To see the information on current connection, follow the instructions in step 5 of the preceding section **Connecting to a wired network**.

TV remote

This function allows you to turn a smart device into a sophisticated remote control, providing more features than your normal TV remote control. You can then control your TV through your smart device.

1. Select **Network > TV Remote**, then press **OK** to enter the **TV Remote** menu. You will see details for downloading the TV Remote application and other related information.

The following instructions are based on the example of a laptop.

2. Download and install into the laptop the correct TV Remote application for the laptop.
3. Make sure the laptop and the TV are in the same home LAN (local area network) or network segment.
4. Run the TV Remote application on the laptop, it will search and communicate with the TV automatically to enable the TV Remote functionality.
5. Once the TV and the laptop are linked as described in step 4, you will be able to enjoy the extra features of the TV Remote function.
6. To quit the TV Remote function, press **EXIT** on the remote control.

Miracast

*(*not available for some models)*

Miracast allows you to share screen and sound of your device such as a smartphone or a tablet to your TV, wirelessly (i.e. without cables). This makes it possible to view on your TV, at the same time, what your smartphone or tablet is showing. For example, you can launch a video on your smartphone and display it simultaneously on your TV, or use your tablet as game controller with content displayed on the big screen of your TV.

Whenever you want to use Miracast, you must first activate this function in your TV. To do it follow the steps below:

1. Press **MENU** on the remote control and select **Network > Miracast**, then press **OK** to enter. You will see details for the Miracast function.
2. Find the Miracast function in your device. Different devices may have different names for this function.
3. Then click the "connection" function on the device. If connected successfully, you will see on your TV screen what the device is showing.

Note: TCL does not guarantee that the use of the Miracast function will be smooth or error-free

since not all devices are compatible with the TV Miracast function.

Chapter 7 - DLNA (Share & See)

*Note: This manual covers products with either **Share & See** or **DLNA** function. **Share & See** is DLNA-compatible.*

Connecting to your PC

Make sure to set up a wired or wireless connection from your TV to a router first. Then connect your PC to your router either through a network cable or wirelessly. Also make sure to select **Network > Network settings > Internet Connection**, then **On**, and that your computer firewall won't block the connection.

Enabling DLNA function

Select **Network > DLNA**, and set it to **On**.

Follow the steps in turn specified hereafter, then you can enjoy recorded video, image and music saved on your PC.

Adding media from your PC for sharing

Install a DLNA media server on your PC. The simple and familiar server you may install is Microsoft Windows Media Player 11 and 11 above. Follow the instructions below to allow your TV to access the designated files on your PC.

1. Open the Microsoft Windows Media Player 11.
 - Select **Library > Media sharing**.
 - Check the checkbox **Share my media to**.
 - Select the icon of the TV set connected to your PC.
 - Select **Allow** to allow the TV set to access your PC, and select **OK** to enable the access.

*Note: Use the **Settings** button to customize your desired settings.*

2.
 - Select **Library > Add to Library**.
 - Select your personal folders or folders of other users that you can access for sharing.
 - Select **Add** and press **OK** to enable the addition.

DLNA application

Select **Media** in the main menu and press **OK** to enter media center. Then you can view photos, listen to music or watch videos, which are stored on your PC.

Note:

- If **DLNA** is switched on, the TV will display the list of available DLNA servers which are available in local network.
- Supported file formats:
 - Photo: JPEG
 - Music: LPCM
 - Video: MPEG2

HbbTV (Hybrid broadcast broadband TV) is a service offered by certain broadcasters and available only on some digital TV channels. HbbTV delivers interactive television over both broadcast and broadband Internet. These interactive features are added to and enrich the normal digital programmes, and include services such as digital teletext, electronic programme guide, games, voting, specific information related to the current programme, interactive advertising, information magazines, catch-up TV, etc.

There are two modes:

- In the broadcast mode, your TV does not need to be connected to the Internet. You will be able to receive those HbbTV services broadcast at the same time as the programme being watched, such as specific and additional information related to the programme. An on-screen indication (for example, red button) will invite you to press the red button on your remote control to access the service.

Figure 6 (source: ETSI) gives such an example.




Figure 6

- In the broadband mode, your TV has to be connected to the Internet. In addition to the broadcast programme being watched, you can access the same services as in broadcast mode and also many other Internet-delivered interactive services such as VOD (Video On Demand) or catch-up TV.

Figure 7 (source: ETSI) gives such an example.



Figure 7

To fully enjoy HbbTV, you need to connect your TV to the Internet (refer to section **Network connection**).

Notes:

- You cannot download files to your TV with HbbTV function.
- An application on HbbTV may malfunction temporarily depending on the circumstances of the broadcast station or application provider.
- An application is only available for use on HbbTV when the TV network is connected to an external network. The application may malfunction depending on the network conditions.

HbbTV access

1. Press **MENU** on the remote control, then select **Settings > HbbTV mode**.

2. Press **◀/▶** to select **On**.
3. When you tune to a TV digital channel that offers HbbTV, this will be signalled to you by an on-screen indication (generally a red button, but other colour buttons may also be used). Press the indicated **colour button** to open the interactive pages.
4. Use **▲/▼/◀/▶** and the colour buttons to navigate through the HbbTV pages and press **OK** to confirm.

HbbTV deactivation

To avoid disturbances that may be caused by HbbTV broadcasting tests, you can turn off the HbbTV function:

1. Select **Menu > Settings > HbbTV mode**.
2. Then press **◀/▶** to select **Off**.

Allows you to enjoy Internet Applications (Apps), specially adapted Internet websites for your TV. You can control the Apps with the TV remote control.

WARNING:

- Configure the network settings before using **Smart TV**.
- Slow responses and/or interruptions may occur, depending on your network conditions.
- If you experience a problem using an application, please contact the content provider.
- According to circumstances of the content provider, an application's updates or the application itself may be discontinued.
- Depending on your country's regulations, some applications may have limited service or not be supported.

Access Smart TV Applications (Apps)

1. Select **Smart TV** in the main menu and press **OK** to display the smart TV home page. The App services depend on the country. Select **country**, press **OK** to enter, then press **▲/▼/◀/▶** to select all the available country options and press **OK** to confirm. Then select **close** and press **OK** to go back to the smart TV home page.

Shortcut operation: Press **Smart TV** on the remote control to display the smart TV home page directly.

2. Use **▲/▼/◀/▶** to select an App and press **OK** to enter.
3. Internet browsing is available with Smart TV portal application. It can be accessed via the icon in the portal or via the green button when TV portal page is displayed.

Note: Since the connection with internet takes time, it's recommended that you wait a few minutes to use the smart TV feature after activation of TV from standby.

Chapter 10 - Other information

Password in Parental Control

- The default password is 1234. You can change it to a new one.
- The super password is 0423. If you forget your code, enter the super password to override any existing codes.

Troubleshooting

Please check the following list before requesting service.

There is no picture or sound.

- Make sure the power cord is properly inserted in the power outlet.
- Make sure the source type is set correctly.
- Make sure the antenna is properly connected.
- Make sure the volume is not set to minimum or the sound is not set to mute.
- Make sure the headphones are not connected.
- The TV may be receiving a signal other than from TV broadcasting stations.

Picture is not clear.

- Make sure the antenna cable is properly connected.
- Consider whether your TV signal is being properly received.
- Poor picture quality can occur due to a VHS camera, camcorder, or other peripheral being connected at the same time. Switch off one of the other peripherals.
- The 'ghost' or double image may be caused by obstruction to the antenna due to high-rise buildings or hills. Using a highly directional antenna may improve the picture quality.
- The horizontal dotted lines shown on the pictures may be caused by electrical interference, e.g., hair dryer, nearby neon lights, etc. Turn off or remove these.

Picture is too dark, too light or tinted.

- Check the colour adjustment.
- Check the brightness setting.
- Check the sharpness function.

Remote control does not work.

- Check the batteries of the remote control.
- Make sure the remote sensor window on the TV front is not under strong fluorescent lighting.
- Try to clean the remote sensor window on the TV front with a soft cloth.

If the above suggestions do not solve your technical issue, please refer to the warranty card for service information.

Television specifications

TV Broadcasting	PAL/SECAM BG/DK/I/LL'
Receiving channels	VHF/UHF/Cable
Tuner type	Frequency synthesized

Operating Conditions

Temperature 5°C - 35°C (41°F - 95°F)
Humidity 20 - 80% (non-condensing)

Storage Conditions

Temperature -15°C - 45°C (5°F - 113°F)
Humidity 10 - 90% (non-condensing)

OSS Notice

This product uses some software programs which are distributed under the Independent JPEG Group.

This product uses some software programs which are distributed under the Freetype Project.

This product uses some software programs which are distributed under the OpenSSL Project.

This product uses some software programs which are distributed under the zlib license.

This product uses UNICODE software programs which are distributed under IBM Open source license.

This product uses libpng software programs which are distributed under OSI Certified Open source license.

This product uses Expat, Libcurl, c-ares software programs which are distributed under MIT license.

This product uses some software programs which are distributed under the GPL/LGPL.

GPL software: Linux Kernel, Busybox, SquashFS, mtd-utils, e2fsprogs, BlueZ, Dbus, Glib, NTFS-3G Read/Write Driver, samba, iconv, Linux File System FTA.

LGPL software: DFB, SAWMAN, ALSA.

[Legal Statement] of TCL - manufacturer of this TV set

Due to the various capabilities of products featuring the SmartTV - Services, as well as limitations in the available content, certain features, applications, and services may not be available on all devices or in all territories. Some features on SmartTV may also require additional peripheral devices or membership fees that are sold separately. Please visit our website for more information on specific device information and content availability. The services and availability of content through SmartTV are subject to change from time to time without prior notice.

All content and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and/or other intellectual property laws. Such content and services are provided solely for your personal noncommercial use. You may not use any content or services in a manner that has not been authorized by the content owner or service provider. Without limiting the foregoing, unless expressly authorized by the applicable content owner or service provider, you may not modify, copy, republish, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner

or medium any content or services displayed through this device.

YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF THE DEVICE IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE AND ACCURACY IS WITH YOU. THE DEVICE AND ALL THIRD PARTY CONTENT AND SERVICES ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED. TCL EXPRESSLY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE DEVICE AND ANY CONTENT AND SERVICES, EITHER EXPRESS OR, IMPLIED, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, OF SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, OF ACCURACY, OF QUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TCL DOES NOT GUARANTEE THE ACCURACY, VALIDITY, TIMELINESS, LEGALITY, OR COMPLETENESS OF ANY CONTENT OR SERVICE MADE AVAILABLE THROUGH THIS DEVICE AND DOES NOT WARRANT THAT THE DEVICE, CONTENT OR SERVICES WILL MEET YOUR REQUIREMENTS, OR THAT OPERATION OF THE DEVICE OR SERVICES WILL BE UNINTERRUPTED OR ERROR-FREE. UNDER NO CIRCUMSTANCES, INCLUDING NEGLIGENCE, SHALL TCL BE LIABLE, WHETHER IN CONTRACT OR TORT, FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, ATTORNEY FEES, EXPENSES, OR ANY OTHER DAMAGES ARISING OUT OF, OR IN CONNECTION WITH, ANY INFORMATION CONTAINED IN, OR AS A RESULT OF THE USE OF THE DEVICE, OR ANY CONTENT OR SERVICE ACCESSED BY YOU OR ANY THIRD PARTY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Third party services may be changed, suspended, removed, terminated or interrupted, or access may be disabled at any time, without notice, and TCL (manufacturer of Thomson branded TVs) makes no representation or warranty that any content or service will remain available for any period of time. Content and services are transmitted by third parties by means of networks and transmission facilities over which TCL has no control. Without limiting the generality of this disclaimer, TCL expressly disclaims any responsibility or liability for any change, interruption, disabling, removal of or suspension of any content or service made available through this device. TCL may impose limits on the use of or access to certain services or content, in any case and without notice

or liability. TCL is neither responsible nor liable for customer service related to the content and services. Any question or request for service relating to the content or services should be made directly to the respective content and service providers.

TCL declares that this TV is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC (if delivered with WiFi access, built-in or USB dongle). The official declaration of conformity may be found at www.thomsonTV.eu in support area.